



INSTRUCTIONS

ST Safety Rope Instructions

- 1 Place non-ratchet hook securely on the middle of the handle of the lead shopping cart.



- 2 Place ratchet hook securely on the middle of the handle you will use to push the line of carts.



- 3 Engage the C3 ST Safety Rope by pulling the rope through the ratchet with moderate force to create lift. **Do not over tighten.**



- 4 To remove the C3 ST Safety Rope, ease tension—gently lift up on the handle of the cart you push—while simultaneously engaging the release clip.

Important: Use only your thumb or the release-assist device (attached to the C3 ST Safety Rope handle) to pull the release clip.